



AIA: AIRPORT INFLUENCE AREA: Refer all plats and development plans to the Airport Authority for review. Comply with FAR Part 77. Require Avigation Easement by landowner and Public Disclosure to prospective buyers and tenants. Residential and other noise sensitive development requires a 7-day noise test and development is prohibited/not recommended in areas at DNL 65 or above.

RDA: RESTRICTED DEVELOPMENT AREA: Prohibit new residential and other noise sensitive development. Building height must comply with FAR Part 77 surface criteria, existing or future, whichever is more restrictive.

BZ: BUFFER ZONE: Recommend no new residential or other noise sensitive development. Governmental entity with zoning and building permit authority to develop specific restrictions.

AZ: APPROACH ZONE: Prohibit new residential and other noise sensitive development. Building height must comply with FAR Part 77 surface criteria, existing or future, whichever is more restrictive.

RPZ: RUNWAY PROTECTION ZONE: No structures permitted.

