



CENTENNIAL AIRPORT'S VEHICLE SAFETY RULES

In order to provide and maintain a safe and secure ramp area, the Airport Authority requires that at all times, vehicle operators adhere to the following vehicle safety rules:

1. No thru traffic is allowed on the ramp. Vehicles are only permitted to access the ramp to go directly to or from their aircraft or hangar. You must use the gate closest to your destination. If access to another area of the ramp is needed, you must exit through the nearest gate and re-enter through the gate closest to your next destination.
2. You must never follow another vehicle through an access gate. Always wait for the gate to close, then scan your card to access the gate. Always wait for the gate to fully close behind your vehicle before driving away.
3. Vehicles may not exceed 20 miles per hour on the ramp. Utilize slower speeds when appropriate.
4. Vehicles entering the ramp must be registered with the Airport Authority and display an airport decal on their rear window.
5. Any vehicle that is not registered with the Airport Authority must be accompanied at all times by a registered vehicle displaying a valid decal while on the ramp.
6. Vehicles must always yield to aircraft. Also yield to pedestrians and emergency equipment.
7. Vehicles may not follow a taxiing aircraft closer than 100 feet and never pass around an operating aircraft, except to the rear.
8. Vehicles parked in non-hangared tied downs must park between the tie down cables parallel to other aircraft. Do not park in other tenant's tie down spots or block access to another aircraft.
9. Unless approved or escorted by Airport Operations, motor homes and trailers of any kind are not permitted on the ramp.
10. Vehicles are not permitted on the west ramp taxilane between A-1 and A-8 or the south ramp taxilane between C-1 and C-5.
11. All vehicle operators are required to comply with the directives of Airport Authority personnel and obey all traffic signs.

Failure to follow these rules may result in revocation of gate card access.

If you see a violation, contact Airport Operations at 303-877-7307.



CENTENNIAL
AIRPORT

VEHICLE RESTRICTED AREAS

-  Movement Area - NO VEHICLES
-  NO VEHICLES
-  Limited Vehicle Access – Driving to/from Nearest Gate and Aircraft/Hangar Only – NO THROUGH TRAFFIC

MOVEMENT AREA - NO VEHICLES

MOVEMENT AREA - NO VEHICLES

